

Liquid Entrainment on Trays



Degree of liquid entrainment is depending on density difference liquid / gas, viscosity, surface tension and vapour velocity.

Possible reasons for excessive vapour velocity:

- Vapour cross flow area too small selected
- Vapour cross flow area is reduced due to fouling / solids
- damaged valves, sharp edge sieve holes

I B E Ingenieurbüro Esper GmbH D-67269 Grünstadt, Bahnhofstraße 16 Tel +49 6359 949390 E-Mail ibe@ibe-engineering.com